



Excess flow valve

Produktbeschreibung

Excess flow valve used to cut off the gas supply in the case of excess flow, if a pipe ruptures for example.Suitable for installation downstream of reduction units such as those in stations for example.

Normen

UNI EN ISO 9539 | UNI 11627

Komponenten

CW614N brass body.
Stainless steel springs.

Technische Daten

CODE	GAS	Q max.	INLET CONNECTION	OUTLET CONNECTION
C0204	GAS	5,2 Nm³/h	G3/8" F L	G3/8" M L
C0204A	OXYGEN	12 Nm³/h	G3/8" F R	G3/8" M R
C0204B	CARBON DIOXIDE	5,2 Nm³/h	G1/4" F R	G1/4" M R
C0204C	CARBON DIOXIDE	5,2 Nm³/h	G3/8" F R	G3/8" M R

Behringer S.r.l. via Gualco 4, 16165 Genova ITALY
T +39 010 8309103 **F** +39 010 8309183 **e-mail** info@behringer.it **C.F.** e **P.I.** 01167840998