



Welding cutting and heating devices



Ar/CO₂ flowmeter

Product description

The column flowmeter is used to regulate the inert gas flow (Argon or Carbon Dioxide) when welding. It can be connected to the gas distribution network using a G 1/4" M R threaded connection; it has a hose connector for Ø 6 mm hoses on the outlet. The adjuster knob on the device can be used to regulate the flow from 0 l/min to 30 l/min.

Technical data

CODE	ITEM
C0764E	Ar/CO ₂ flowmeter

